파 일 번 호	품 명	모 델 명	비 고
UL, cUL (E 117960)	안전도어 스위치 (sec.12)	KSD, A, B, 2B, AB, Key-H,V,C	
	Limit Switch(구형)	KH-8010 S, C	
		KH-8010-RP, KH-8010-V1	
	Limit Switch (KL Series)	KLCA2, CA2-2, CA12, CA12-2, CL, CL-2, CA31-41, CA32-42,CA32-43, CA32-44, D, D2, D28, D3, SD2, NJ, NJ-A2, T,A,M, LE, LD, 2,3, TH,TC, SA,SS,S50,SA50, SC-A6SW	
	RELAY	KH-102-2C, 3C, KH-103-1C, 2C, 3C, 4C, H2C,	~~KH-105단종~~
	Cam Switch	KCR-303 R,H,P,F/PL	
	Illuminated push Button Switch	KBL25/30/W M,MP,AT,AP,EA,EM,ER,EP/L/1A,2A,3A 1C,2C,3C,125D/R,G,Y,B,W	
	48-TIMER	KTM-1S	
	Φ22 제어용 스위치	KH-2201/S, EB, ER, AT KH-2201SL,KH-2501SL,KH-3001SL KH-2202/2S,2L,2K,3S,3L,3K,2AS,2AL,2AK,3AS,3AL,3AK, 3RS,3RL,3RK/1,2 KH-2204/L/EB, ER, P, AT/1,2,3/TL	
	NF30 Series	NF30/L,P,B,S,K/M,A,2S,3S,A2S,A3S,3RS,2L,3L,A2L,A3L, 3RL,2K,3K,A2K,A3K,3RK/1A,2A,3A,1C,2C,3C/R,G, Y,W,B,O/1,2	
	22,25,30Φ Series	KPB,KEPB/22,25,30/W/M,MS,ML,AT,EM,EA,ER,EP/S/R, G,Y,B,W,BK	
	25,30Φ Selector or Key Series	KSL/25/30/W/S2,L2,S3,L3,AL2,AS3,RS3,RL3,K2,AK2,K3, AK3,RK3	
	Micro Switch(소형)	KH-9012-/PB,PBF,HL,HLL,HLR,HRL,HRM,HRS B or C KH-9012-5/PB,PBF,HL,HLL,HLR,HRL,HRM,HRS B or C	B type 생산 중단
	Micro Switch(일반형)	KH-9015-/PBF,PBL,PBS,RP,CRP,HL,HLL,HRL,HRM,HRS, HRSH,HRSW,HLZ,HP KH-9115-/HRS	
	NF25 or 30 Series (신형 매입형 스위치)	1)Pilot Lamp 2)조광형 push Button Switch 3)push Button Switch 4)Selector Switch 5)Key Selector Switch	Series Model All

파일 번호	품 명	모 델 명	비 고
UL, cUL (E 232835)	Terminal Block	KH-65100, KH-65200, KH-65350	
UL, cUL (E 313518)	Relay Socket	KH-TDR-R8, KH-TDR-R11, KH-RS-R8, KH-RS-R11 KH-RS-14N, KH-RS-14M, KH-RS-14N-8 and KH-RS-14M-8.	
UL, cUL (E 191305)	Pilot Lamp Φ22 Series	KH-2203/L/1, 2, 3/TL	
	Pilot Lamp Φ25,Φ30 Series	KPL-25, 30W L type : 1A, 2A, 3A, 125DC, 1C,2C,3C R,G,Y,B,W/ac/dc KPL-25, 30W Filament type : 1A, 2A, 3A, 125DC, 1C,2C,3C R,G,Y,B,W/ ac/dc	
	Φ16 Series Illuminated push Button Switch	KBL / KPB16 S, R/M, AT/L/1C,2C,3C/R,G,Y,O,W,B/1,2	
	Φ16 Series Illuminated push Button Switch	KEBL / KEPB16, 160/ER/S/L/1C,2C,3C/R,G,Y/1A,2A,1B, 2B,1A1B	
	Φ16 Series Selector Switch	KSL16/S,R/S2,S3,K2,K3/F,L/1C,2C,3C/R,G,Y,O,W,B/1,2	
	NF22 Series	NF22/L,P,B,S,K/M,A,2,3,A2,A3,K2,K3,AK3/1C,2C,3C/R,G, Y,W,B,O/1,2	
	Square Lights	KH-5030L/5040L followed by -12,-24, DC48, DC110, DC125, DC220, 12T, 22T followed by T, PCK, NCK or Blank	2021.06.30
	Cam Switch	Models K, followed by C, followed by 30A or 20D, followed by 6, 6S, A, 24D or P, maybe followed by T, maybe followed by R, C, CL, 3M, 6M or 9M, followed by four to seven digits alphanumeric combination, followed by E, T, P, R, H, S or M.	
		Models KSG, followed by 22, 25 or 30, maybe followed by K, maybe followed by N, maybe followed by R, C, CL, 3M, 6M or 9M, followed by four to seven digits alphanumeric combination, followed by E, T, P, R, H or S.	
		Models KG, followed by 4, 6, 6S, A, 24D or P, maybe followed by T, maybe followed by R, C, CL, 3M, 6M or 9M, followed by four to seven digits alphanumeric combination, followed by E, T, P, R, H, S or M.	

UL 인증 등록 대장 (3/3)

파일 번호	품 명	모 델 명	비 고
UL, cUL (E 487989)	**KSE Series Emergency Stop Switch**	KSEB 22, 25, 30 Series KSEP 22, 25, 30 Series	CCN/NISD Listed
UL, cUL (E 191305)	**NS22 Series**	Open Type, Control Switches, Models NS22, followed by L, P, B, S, SL, K or D, followed by M, A, EM, ER, 2, 3, A2, A3 or 3R, followed by Blank or L, followed by 1AL, 2AL, 1A, 12A, 2A, 3A, 24A, 4A, 5A, 1C, 2C, 3C, 1D, 2D, 12D, 3D, 4D or 24D, followed by R, G, Y, B, W, O or BK, maybe followed by alphanumeric characters.	2018.11.23
UL, cUL (E 513097)	**POTO SENSOR KPS-CTV KPS-CTVN**	Photoelectric sensors, Models KPS followed by -CT, followed by V or H, followed by N, P or blank, followed by S, Y, 220, 270, 360 or blank	2020.01.10
UL, Cul (E 191305)	**Safety door Switch KS2D Series**	KS2D Series, Models KS2D, followed by -3B, -2B, -2BA, -AB, -B or - A, followed by -H, -V or -C.	2022.11.30
UL, Cul (E 191305)	*NEW Safety door Switch KESD Series*	*KESD Series,* *Models KESD,* *followed by -M* *followed by A, B, or C* *followed by -H, -V or -C.*	*2023.10.05*